





CUT TREAD TO LENGTH.

MARK OFF LINES AT DESIRED ANGLE, E.G., 45°, 60°, ETC., FROM TOP RIGHT CORNER DOWN LEFT IN DESIRED INCREMENTS, E.G., 3°, 4°, ETC.

FILL IN EVERY OTHER SPACE WITH MASKING TAPE STARTING WITH FIRST AREA TO LEFT OF UPPER R/H CORNER.

FILL UNTAPED AREAS WITH YELLOW RESIN. THEN REMOVE TAPE.

AFTER 12 HRS. (MINIMUM), TAPE OVER YELLOW RESIN.

FILL VOIDS WITH BLACK RESIN.
THEN REMOVE TAPE FROM YELLOW RESIN
AND LET SET 12 HRS. (MINIMUM).

Fig. 9